

STORAGE INSTRUCTIONS REPLACEMENT ACCESSORIES

STORAGE INSTRUCTIONS

When not using your humidifier for an extended period of time:

1. Dispose of the filters. DO NOT leave in unit.
2. Clean, rinse and thoroughly dry the humidifier as directed in weekly maintenance. DO NOT leave any water in the unit when storing. Leaving water in the unit may render the unit inoperable for the following season.
3. Place the humidifier in the original carton and store in a cool, dry place.
4. Order your replacement filter for next year's use.

REPLACEMENT ACCESSORIES

To order the replacement accessories you can do any of the following:

- Visit your local retailer
- Go to www.bionaire.com
- Call Consumer Service at 1-800-253-2764

If you have any questions regarding your product or would like to learn more about other Bionaire® products, please contact our Consumer Service Department at 1-800-253-2764 or visit our website at www.bionaire.com.

TROUBLESHOOTING FREQUENTLY ASKED QUESTIONS

TROUBLESHOOTING		
TROUBLE	PROBABLE CAUSE	SOLUTION
• Unit does not turn on.	<ul style="list-style-type: none"> ☛ Not plugged in. ☛ Outlet not functioning. 	<ul style="list-style-type: none"> ✓ Plug in unit. ✓ Have outlet replaced by a licensed electrician.
• Mist output minimal to none.	<ul style="list-style-type: none"> ☛ Filter has not absorbed water. ☛ Cool mist is invisible. 	<ul style="list-style-type: none"> ✓ Wait 30 minutes for filter to absorb water. ✓ Operate in High (3) setting.
• Filter turns brown.	☛ The filter has absorbed minerals.	<ul style="list-style-type: none"> ✓ Replace your filter (HWF75/SF221) by calling 1-800-253-2764, or visiting www.bionaire.com.
• FilterCheck® is not working.	☛ Takes 60 minutes to register.	<ul style="list-style-type: none"> ✓ Allow the humidifier to run continuously for 60 minutes for the FilterCheck® Indicator to reflect the filter condition.
• Humidifier continuously displays 21%.	☛ Humidity at the humidifier is at or below 21%.	<ul style="list-style-type: none"> ✓ Continue to operate humidifier to raise the room humidity.
• Humidifier continuously displays 90%.	☛ Humidity at the humidifier is at or above 90%.	<ul style="list-style-type: none"> ✓ Stop operating the humidifier if the humidity level is too high.

FREQUENTLY ASKED QUESTIONS	
Question	Answer
• What are the variables that affect run time?	<p>The estimated run time for this humidifier is based on average room conditions. The actual run time of your humidifier is dependent on numerous variables such as:</p> <ul style="list-style-type: none"> ✓ Air exchange in the room where the humidifier is placed. ✓ Room construction of the room where the humidifier is placed. ✓ Temperature of the room where the humidifier is placed. ✓ Humidity levels in the room where the humidifier is placed. ✓ Movement of occupants and the opening and closing of doors in the room where the humidifier is placed. ✓ Home furnishings in the room where the humidifier is placed.
• How do I remove film on water tank?	<ul style="list-style-type: none"> ✓ See Daily Maintenance instructions. Regular cleaning is recommended.
• How can I extend the run time?	<ul style="list-style-type: none"> ✓ Run your unit on the lowest setting. ✓ If your unit has electronics, set it to your desired humidity level. The unit will turn on and off, which will extend the run time. ✓ Fill the tank all the way full, place it on the base, let the water empty into the base until it stops bubbling, then refill the tank full again. This ensures maximum water capacity and will extend run time.

WARRANTY INFORMATION

1 YEAR LIMITED WARRANTY

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions or if in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of one year from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product. Doing so will void this warranty. This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. JCS dealers, service centers, or retail stores selling JCS products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use of improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than JCS or an authorized JCS service center. Further, the warranty does not cover: Acts of God, such as fire, flood, hurricanes and tornadoes.

What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages caused by the breach of any express, implied or statutory warranty or condition.

Except to the extent prohibited by applicable law, any implied warranty or condition of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty.

JCS disclaims all other warranties, conditions or representations, express, implied, statutory or otherwise. JCS shall not be liable for any damages of any kind resulting from the purchase, use or misuse of, or inability to use the product including incidental, special, consequential or similar damages or loss of profits, or for any breach of contract, fundamental or otherwise, or for any claim brought against purchaser by any other party.

Some provinces, states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from province to province, state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any questions regarding this warranty or would like to obtain warranty service, please call 1-800-253-2764 and a convenient service center address will be provided to you.

In Canada

If you have any questions regarding this warranty or would like to obtain warranty service, please call 1-800-253-2764 and a convenient service center address will be provided to you.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions, located at 20 B Hereford Street, Brampton, Ontario L6Y 0M1. If you have any other problem or claim in connection with this product, please write our Consumer Service Department. **PLEASE DO NOT RETURN THIS PRODUCT TO ANY OF THESE ADDRESSES OR TO THE PLACE OF PURCHASE.**

© 2011 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All Rights Reserved. Distributed by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, Boca Raton, Florida 33431.

Printed In China

BIONAIRE®

pure indoor living



COOL MIST HUMIDIFIER



MODEL: BCM3656

Filter #: HWF75/HF221
Filter Type: WICK

Instruction Leaflet

Read instructions before operating. Retain for future reference.

Questions? Comments? Call 1-800-253-2764 in North America.

LIMPIEZA / MANTENIMIENTO ACCESORIOS DE REPUESTO

Mantenimiento diario

1. Asegúrese de apagar y desenchufar la unidad del tomacorriente.
2. Desmonte el casco y los tanques del humidificador y colóquelos en el fregadero o en la tina.
3. Lleve la base de la unidad al fregadero o a la tina, quitele el filtro de mecha, coloque la base en el fregadero, drene el agua remanente, enjuague completamente para remover cualquier sedimento o suciedad, limpie frotando con un paño y seque con una toalla de tela o papel.
4. Drene el agua de los tanques en el fregadero y enjuáguelos completamente. Limpíelos frotando con un paño y séquelos con una toalla de tela o de papel.
5. Vuelva a instalar el filtro, el caso y vuelva a llenar el tanque con agua corriente como se indicó anteriormente en las instrucciones para el llenado. No lo llene de más.
6. Siga las instrucciones de operación.

Mantenimiento semanal

1. Repita los pasos 1 al 4 anteriores.
2. Para limpiar la base, llénela parcialmente con una taza de 8 onzas de vinagre blanco sin diluir o con Cleanse Clean® solución (modelo S1710) del fabricante. Deje actuar esta solución en la base por 20 minutos, mientras limpia las superficies interiores con un cepillo suave. Quite el sarro de la base con un trapo humedecido con vinagre blanco sin diluir.
3. Enjuague con agua tibia limpia para extraer la solución limpiadora antes de desinfectar el tanque.

Para desinfectar la base y los tanques del humidificador :

1. Llene cada tanque hasta la mitad con agua y 1/2 cucharadita de blanqueador de cloro.
2. Llene cada tanque hasta la mitad con agua y 1/2 cucharadita de blanqueador de cloro.
3. Deje que la solución trabaje por 20 minutos, sacudiendo los tanques de vez en cuando. Moje todas las superficies.
4. Vacíe cuidadosamente la base y los tanques después de 20 minutos y enjuague hasta que ya no se pueda detectar el olor a cloro. Seque con una tela limpia o con toalla de papel.

5. Verifique el indicador FilterCheck® para ver si es el momento de reemplazar los filtros. Dependiendo de la dureza del agua en su zona, puede ser necesario cambiar el filtro cada 1-2 meses. Vuelva a colocar la mecha del filtro.
6. Vuelva a llenar los tanques de agua como se indica con agua fría, vuelva a colocar la carcasa del humidificador, y gire la perilla de control a encendido.

INSTRUCCIONES PARA GUARDAR

Cuando no utilice su humidificador durante un periodo prolongado de tiempo:

1. Elimine los filtros, NO los deje dentro de la unidad.
2. Limpie y seque bien el humidificador según se detalla anteriormente en la sección: instrucciones de mantenimiento semanales. NO deje agua dentro de la unidad cuando guarde el humidificador. Si queda agua, la unidad podría quedar inutilizable para la próxima temporada.
3. Coloque el humidificador en su empaque original y guárdelo en un lugar fresco y seco.
4. Encargue su filtro de repuesto para el próximo año.

ACCESORIOS DE REPUESTO

Puede ordenar accesorios de repuesto de una de las siguientes formas:

- Visite su distribuidor local
- Valla a www.bionaire.com
- Llame a servicio al consumidor al 1-800-253-2764

Si tiene preguntas relacionadas con este producto o si está interesado en conocer otros productos Bionaire®, póngase en contacto con nuestro Departamento de Servicio al Cliente: llame al 1 (800) 253-2764 o visite nuestro sitio web www.bionaire.com.

DIAGNÓSTICO DE PROBLEMAS PREGUNTAS FRECUENTES

DIAGNÓSTICO DE PROBLEMAS		
PROBLEMA	POSIBLE CAUSA	SOLUCIÓN
• La unidad no se enciende.	<ul style="list-style-type: none"> ☛ No está enchufada. ☛ El omacorriente no funciona. 	<ul style="list-style-type: none"> ✓ Enchúfela. ✓ Haga reemplazar el tomacorriente por un electricista matriculado.
• Salida de vapor mínima o nula.	<ul style="list-style-type: none"> ☛ El filtro no ha absorbido el agua. ☛ La niebla fría es invisible. 	<ul style="list-style-type: none"> ✓ Espere 30 minutos para que el filtro absorba el agua. ✓ Funcionamiento en configuración High (alta) (3).
• El filtro se pone marrón.	☛ El filtro ha absorbido minerales.	<ul style="list-style-type: none"> ✓ Reemplace su filtro (HWF75/SF221) llamando al 1-800-253-2764, o visite www.bionaire.com.
• El FilterCheck® no está funcionando.	☛ Demora 60 minutos registrarse.	<ul style="list-style-type: none"> ✓ Permita que el humidificador funcione continuamente durante 60 minutos para que el indicador del FilterCheck® refleje el estado del filtro.
• El humidificador muestra constantemente un 21%.	☛ La humedad del humidificador está en un nivel inferior o igual al 21%.	<ul style="list-style-type: none"> ✓ Permita que su humidificador siga funcionando para aumentar la humedad de la habitación.
• El humidificador muestra constantemente un 90%.	☛ La humedad del humidificador se encuentra en 90% o más.	<ul style="list-style-type: none"> ✓ Detenga el funcionamiento del humidificador si el nivel de humedad es muy alto.

PREGUNTAS FRECUENTES	
PREGUNTAS	RESPUESTAS
• ¿Cuáles son las variables que afectan el tiempo de funcionamiento?	<p>El tiempo de funcionamiento estimado de este humidificador está basado en las condiciones ambientales promedio. El tiempo de funcionamiento actual de su humidificador depende de varios factores tales como:</p> <ul style="list-style-type: none"> ✓ El intercambio de aire en el cuarto donde se encuentra el humidificador. ✓ La estructura del cuarto donde se encuentra el humidificador. ✓ La temperatura del cuarto donde se encuentra el humidificador. ✓ Los niveles de humedad en el cuarto donde se encuentra el humidificador. ✓ La actividad de los ocupantes y la secuencia en que se abren y cierran las puertas del cuarto donde se encuentra el humidificador. ✓ El número de muebles presentes en el cuarto donde se encuentra el humidificador.
• ¿Cómo quito la película del tanque de agua?	<ul style="list-style-type: none"> ✓ Consulte las instrucciones diarias de mantenimiento. Se recomienda una limpieza regular.
• ¿Cómo puedo extender el tiempo de funcionamiento?	<ul style="list-style-type: none"> ✓ Haga funcionar la unidad en el modo más bajo. ✓ Si su unidad tiene electrónicos, ajústela al nivel de humedad deseado. La unidad se encenderá y apagará, extendiendo el tiempo de funcionamiento. ✓ Llene el tanque al máximo, colóquelo en la base, deje que el agua se vacíe en la base hasta que deje de burbujear, luego llene nuevamente el tanque al máximo. Esto asegura una capacidad máxima de agua que extenderá el tiempo de funcionamiento.

INFORMACION DE LA GARANTIA

GARANTÍA LIMITADA DE 1 AÑO

Sunbeam Products, Inc. operando bajo el nombre de Jarden Consumer Solutions, o en Canadá, Sunbeam Corporation (Canada) Limited operando bajo el nombre de Jarden Consumer Solutions, (en forma conjunta, "JCS"), garantiza que por un periodo de uno año a partir de la fecha de compra, este producto estará libre de defectos de materiales y mano de obra. JCS, a su elección, reparará o reemplazará este producto o cualquier componente del mismo que presente defectos durante el periodo de garantía. El reemplazo se realizará por un producto o componente nuevo o reparado. Si el producto ya no estuviera disponible, se lo reemplazará por un producto similar de valor igual o superior. Esta es su garantía exclusiva. No intente reparar o ajustar ninguna función eléctrica o mecánica de este producto. Al hacerlo eliminará esta garantía. La garantía es válida para el comprador minorista original a partir de la fecha de compra inicial y la misma no es transferible. Conserve el recibo de compra original. Para solicitar servicio en garantía se requiere presentar un recibo de compra. Los agentes y centros de servicio de JCS o las tiendas minoristas que venden productos de JCS no tienen derecho a alterar, modificar ni cambiar de ningún otro modo los términos y las condiciones de esta garantía. Esta garantía no cubre el desgaste normal de las piezas ni los daños que se produzcan como resultado de uso negligente o mal uso del producto, uso de voltaje incorrecto o corriente inapropiada, uso contrario a las instrucciones operativas, y desarme, reparación o alteración por parte de un tercero ajeno a JCS o a un Centro de Servicio autorizado por JCS. Asimismo, la garantía no cubre actos fortuitos tales como incendios, inundaciones, huracanes y tornados.

¿Cuál es el límite de responsabilidad de JCS?

JCS no será responsable de daños incidentales o emergentes causados por el incumplimiento de alguna garantía o condición expresa, implícita o legal.

Excepto en la medida en que lo prohíba la ley aplicable, cualquier garantía o condición implícita de comerciabilidad o aptitud para un fin determinado se limita, en cuanto a su duración, al plazo de la garantía antes mencionada.

JCS queda exenta de toda otra garantías, condiciones o manifestaciones, expresa, implícita, legal o de cualquier otra naturaleza.

JCS no será responsable de ningún tipo de daño que resulte de la compra, uso o mal uso del producto, o por la imposibilidad de usar el producto, incluidos los daños incidentales, especiales, emergentes o similares, o la pérdida de ganancias, ni de ningún incumplimiento contractual, sea de una obligación esencial o de otra naturaleza, ni de ningún reclamo iniciado contra el comprador por un tercero.

Algunas provincias, estados o jurisdicciones no permiten la exclusión o limitación de los daños incidentales o emergentes ni las limitaciones a la duración de las garantías implícitas, de modo que es posible que la exclusión o las limitaciones antes mencionadas no se apliquen en su caso.

Esta garantía le otorga derechos legales específicos y es posible que usted tenga otros derechos que varían de un estado, provincia o jurisdicción a otro.

Cómo solicitar el servicio en garantía

En los Estados Unidos

Si tiene alguna pregunta sobre esta garantía o desea recibir servicio de garantía, llame al 1-800-253-2764 y podrá obtener la dirección del centro de servicio que le resulte más conveniente.

En Canadá

Si tiene alguna pregunta sobre esta garantía o desea recibir servicio de garantía, llame al 1-800-253-2764 y podrá obtener la dirección del centro de servicio que le resulte más conveniente.

En los Estados Unidos, esta garantía es ofrecida por Sunbeam Products, Inc. operando bajo el nombre de Jarden Consumer Solutions, Boca Raton, Florida 33431. En Canadá, esta garantía es ofrecida por Sunbeam Corporation (Canada) Limited operando bajo el nombre de Jarden Consumer Solutions, 20 B Hereford Street, Brampton, Ontario L6Y 0M1. Si usted tiene otro problema o reclamo en conexión con este producto, por favor escriba al Departamento de Servicio al Consumidor. **POR FAVOR NO DEVUELVIA ESTE PRODUCTO A NINGUNA DE ESTAS DIRECCIONES NI AL LUGAR DE COMPRA.**

© 2011 Sunbeam Products, Inc. operando bajo el nombre de Jarden Consumer Solutions. Todos los derechos reservados. Distribuido por Sunbeam Products, Inc. operando bajo el nombre de Jarden Consumer Solutions, Boca Raton, Florida 33431.

149364/9100030007270

BCM3656_11ESM1

Impreso en China

GCDS-BI021223-PH

BIONAIRE®

vida en interiores puros



CON ROCÍO FRESCO HUMIDIFICADOR



MODELO: BCM3656

FILTRO#: HWF75/HF221
FILTRO TIPO: MECHAS

Folleto de Instrucciones


Lea las instrucciones antes de usarlo. Consérvelas para futuras consultas.

¿Preguntas? ¿Comentarios? Llame al 1-800-253-2764 en Norteamérica.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using the appliance.
 2. To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
 3. Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs or near heat registers.
 4. DO NOT place humidifier near heat sources such as stoves, radiators, and heaters. DO locate your humidifier on an inside wall near an electrical outlet. The humidifier should be at least 4 inches (10 cm) away from the wall for best results.
 5. NEVER place humidifier in an area where it is accessible to children. NEVER use humidifier in a dosed room, particularly where a child may be sleeping, resting, or playing (a dosed room may result in excessive humidity).
 6. **WARNING:** Do not attempt to refill humidifier without first unplugging the unit from its electrical outlet. Failure to heed this warning may cause personal injury. Be sure to unplug the unit by pulling on the plug and not the cord.
 7. Never place anything over moisture outlet when the unit is running.
 8. NEVER drop or insert any object into any openings.
 9. DO NOT operate any appliance with a damaged cord or plug, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Return appliance to manufacturer for examination, electrical or mechanical adjustment, or repair.
 10. Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by the manufacturer may cause hazards.
 11. DO NOT use outdoors.
 12. Always place humidifier on a firm, flat, level surface. A waterproof mat or pad is recommended for use under
13. DO NOT allow the Moisture Outlet to directly face the wall. Moisture could cause damage, particularly to wallpaper.
 14. Humidifier should be unplugged when not in use.
 15. NEVER tilt, move, or attempt to empty unit while it is operating. Shut off and unplug before removing the water tank and moving the unit.
 16. This humidifier requires daily and weekly maintenance to operate appropriately. Refer to daily and weekly cleaning procedures. Use only cleaners and additives recommended by the manufacturer.
 17. NEVER use detergents, gasoline, glass cleaner, furniture polish, paint thinner, or other household solvents to clean any part of the humidifier.
 18. Excessive humidity in a room can cause water condensation on windows and some furniture. If this happens, turn the humidifier OFF.
 19. Do not use humidifier in an area where humidity level is in excess of 50%. Use a hygrometer, available at your local retailer or through the manufacturer, to measure the humidity.
 20. DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
 21. Never place housing under water flow or immerse in liquids.
 22. Do not plug in the cord with wet hands: electric shock could result.
 23. Do not pour water in any openings other than the water tank.
 24. To prevent damage to surfaces, do not place humidifier under overhanging surfaces.
 25. NEVER operate unit without water in the tank.



THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.


LEA Y CONSERVE ESTAS IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Debe tomar precauciones básicas de seguridad siempre que utilice artefactos eléctricos para reducir el riesgo de incendio, descarga eléctrica y daños personales, incluyendo lo siguiente:

1. Lea completamente las instrucciones antes de utilizar el artefacto.
 2. Para evitar incendio o descarga eléctrica, enchufe el artefacto directamente en un tomacorriente de 120V CA.
 3. Mantenga el cable fuera de las zonas de mucho tráfico. Para evitar incendios, NUNCA coloque el cable debajo de alfombrillas o cerca de salidas de calefacción.
 4. NO coloque el humidificador cerca de fuentes de calor como estufas, radiadores y calefactores. NO coloque el humidificador contra una pared interna cerca de un tomacorriente. El humidificador debe estar a por lo menos 4" de la pared para obtener el mejor resultado.
 5. NUNCA coloque el humidificador en una zona accesible para los niños. NUNCA use el humidificador en un cuarto cerrado, especialmente donde pueda haber un niño durmiendo, descansando, o jugando (un cuarto cerrado puede resultar en excesiva humedad).
 6. **ADVERTENCIA:** No intente llenar nuevamente el humidificador sin antes desenchufarlo del tomacorriente. El no tener en cuenta esta advertencia puede causar daños personales. Asegúrese de desenchufar la unidad tirando del enchufe y no del cable.
 7. Nunca coloque algo sobre la salida de humedad cuando la unidad esté funcionando.
 8. NUNCA inserte ningún objeto en una de las ranuras.
 9. NO utilice ningún artefacto si el cable o el enchufe están dañados, luego de una falla, o si se ha caído o ha sufrido cualquier tipo de daño. Devuelva el artefacto al fabricante para su inspección, ajuste eléctrico o mecánico, o reparación.
 10. Utilice el artefacto únicamente para el propósito hogareño indicado en este manual. Cualquier uso distinto al recomendado por el fabricante puede causar incendio, descarga eléctrica, o daños personales. El uso de accesorios no recomendados o que no sean vendidos por el fabricante puede ser peligroso.
11. NO utilizar en el exterior.
 12. Siempre coloque el humidificador en una superficie firme, plana y nivelada. Se recomienda el colocar una alfombrilla o bandeja resistente al agua debajo del humidificador. NUNCA lo coloque sobre un tapete o una alfombra, o en un piso que pueda dañarse con el agua o la humedad.
 13. NO haga que la salida de humedad apunte directamente a la pared. La humedad puede causar daños, especialmente al empapelado.
 14. Se debe desenchufar el humidificador cuando no se usa.
 15. NUNCA incline, mueva o intente vaciar la unidad mientras esté funcionando. Apague y desenchufe la unidad antes de quitar el tanque de agua y moverla.
 16. Este humidificador requiere mantenimiento diario y semanal para funcionar correctamente. Refiérase a los procedimientos de limpieza diarios y semanales. Use únicamente limpiadores y aditivos recomendados por el fabricante.
 17. NUNCA use detergentes, gasolina, limpiavidrios, limpiador de muebles, diluyente de pintura u otro solvente hogareño para limpiar ninguna parte del humidificador.
 18. La humedad excesiva en un cuarto puede causar condensación de agua en las ventanas y en algunos muebles. Si sucede esto, apague el humidificador.
 19. No use el humidificador en un área donde el nivel de humedad es mayor al 50%. Use un Higrómetro, disponible en su tienda local o a través del fabricante, para medir la humedad.
 20. NO intente reparar o ajustar ninguna función eléctrica o mecánica de esta unidad. El hacerlo invalidará la garantía. La unidad no contiene partes reparables por el usuario. Toda reparación debe ser realizada únicamente por personal calificado.
 21. Nunca coloque el gabinete debajo de la canilla o lo sumerja en líquidos.

ESTE PRODUCTO TIENE UN ENCHUFE POLARIZADO (una hoja es más ancha que la otra). A fin de disminuir el riesgo de descarga eléctrica, este enchufe está diseñado para insertarse en un tomacorriente polarizado en un solo sentido. Si el enchufe no entra completamente en el tomacorriente, inviértalo. Si aun así no entra, llame a un electricista calificado para instalar un tomacorriente apropiado.

NO MODIFIQUE EL ENCHUFE NI ANULE ESTA FUNCION DE SEGURIDAD DE NINGUNA MANERA.



FEATURES - OPERATIONS

26. Do not move unit after it has been used until unit cools completely.
27. Use both hands when carrying full tank of water.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

CONSUMER SAFETY INFORMATION

NOTE: This is an electrical appliance and requires attention when in use.

NOTE: If moisture forms on the walls or windows of the room, turn off the humidifier. The room already has plenty of humidity and additional moisture may cause damage.

NOTE: DO NOT block air inlet or outlet.

Cord and Plug Installation Safety Instructions:

The length of cord used on this appliance was selected to reduce the hazards of becoming tangled in, or tripping over a longer cord. If a longer cord is necessary an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the humidifier (refer to the rating information placed on the humidifier). Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

HOW COOL MIST WORKS

Your Bionaire® Cool Mist humidifier draws dry air through the rear air intake grill area. This air is then passed through a moisture-laden wick filter, which retains the minerals and deposits in the water. The resulting moist air is directed back into the room from the top air grill.

NOTE: This humidification system provides a cool, invisible moisture output. It is normal not to see the mist.

NOTE: A humidity level below 20% can be unhealthy and uncomfortable. The recommended humidity level is between 40%-50%.

PRE-OPERATING INSTRUCTIONS


1. Be sure the humidifier is switched to OFF and the unit is disconnected from the electrical outlet.
2. Select a location for your humidifier, on a flat surface, about 4 inches (10 cm) away from the wall. DO NOT place the humidifier on a finished floor or near furniture, which can be damaged by too much moisture or water. Place on a moisture-resistant surface.
3. Humidifier can be used with or without wheels. Locate the four wheels in the box. Turn base of humidifier over to reveal underside. Locate the two stationary wheels and push the wheel posts into one end of the base (Figure 1). Locate the two swivel wheels and push the wheel posts into the opposite end of the base (Figure 1).

FILLING THE WATER TANK

1. Remove the tank from the base of the humidifier and bring to the faucet. Turn the tank upside down and twist off the tank cap by turning counter clockwise. Fill tank with cool, fresh tap water. **DO NOT fill with warm water as this may cause leaking. Replace the cap on each tank FIRMLY.**
2. When full, carry each tank to the humidifier and place onto the base (use both hands when carrying each tank). Each tank holds 1.6 gallons of water, and the base holds 1/2 gallons of water.
3. Plug the power cord into a 120V AC electrical outlet.

OPERATING INSTRUCTIONS

Your humidifier is equipped with a technologically advanced Digital Humidistat. You can set the humidifier to run continuously in manual mode or set the Digital Humidistat to your desired humidity setting. The Digital



WHEEL INSTALLATION

- A. STATIONARY WHEELS
- B. SWIVEL WHEELS
- C. UNDER-SIDE OF HUMIDIFIER BASE

FEATURES - OPERATIONS

Humidistat will automatically turn the humidifier ON or OFF, depending on the preset comfort level. The comfort level ranges between 35% and 65% relative humidity.

MANUAL MODE INSTRUCTIONS

1. Plug the humidifier into a 120V AC electrical outlet.
2. The display will show the current room humidity. **NOTE:** The display range is 21% - 90%. If your room humidity level falls below 21%, the unit will display 21. If your room humidity level rises above 90%, the unit will display 90.
3. To start the unit, push the MODE (⊖) button twice within 3 seconds for the HIGH (3) manual setting.
4. Press the button again for the MEDIUM (2) manual setting and again for LOW (1). After the selection is made, the display will return to show the current room humidity.
5. To stop the unit, press and hold the MODE (⊖) button for two seconds, or keep pressing the button until the display reads OFF (OF).

DIGITAL HUMIDISTAT INSTRUCTIONS

To take advantage of the Digital Humidistat, press the MODE (⊖) button until the speed is set in either the AUTO HIGH (A3), AUTO MEDIUM (A2) or AUTO LOW (A1) setting. Then adjust the set humidity by using the up and down buttons. Humidity will increase in increments of 5%. When the humidity level is set, the display will return to show the current room humidity. When the room humidity level rises above the set humidity, the humidifier will stop. When the humidity level drops below the set humidity, the humidifier will turn on automatically.

NOTE: Allow up to 30 minutes for the filter to fully absorb water and for the unit to produce moisture. **NOTE:** The digital humidistat has memory. This means that when you turn the unit back on, it will be at the last setting the humidifier was set at.

If you do not plan to use the humidifier for two or more days, make sure any residual water is drained from the water tank, base and wick filter to prevent algae or bacteria growth.

16 HOUR AUTO ON/OFF TIMER INSTRUCTIONS

The Auto On/Off timer will allow the user two options, to set a time to turn the unit off or to set a time to turn the unit on.

Auto Off Timer

While the unit is running, the off timer can be activated by holding down the up and down buttons simultaneously for 2 seconds, the screen will flash 00 and the up and down arrows can be pushed to adjust the timer up to 16 hours in increments of one, once 16 hours is reached, the next push of the timer button will cycle back to 00 hours. The Timer Light will illuminate to indicate that the Timer is activated. The unit will then shut off after the timer expires (in its current setting). While the unit is running, the timer should stay on even if other modes are being changed. The timer should only be deactivated if the unit is turned off.

Auto On Timer

While the unit is off, the up and down buttons are pressed simultaneously for 2 seconds and the display will flash 00 the up button may then be pushed again to increase the hours to turn on (in its last setting) from 1-16 in increments of 1 hour. The unit will then come on after the timer expires; if the unit is then turned on, the timer will be deactivated. The Timer Light will illuminate to indicate that the Timer is activated. Once 16 hours is reached, the next push of the timer button will cycle back to 00 hours.

REPLACING THE FILTERS

Through normal use, waterborne minerals and sediment become trapped in the wick filter. The harder your water, the greater the amount of minerals in the water, and the more often you will need to change your filter.


You will be able to monitor the life of the filter in your humidifier by checking the FilterCheck® Indicator. The FilterCheck® Indicator will only read the filter condition when the humidifier is in operation.

NOTE: It may take up to 60 minutes of operation for the FilterCheck® Indicator to reflect the filter condition.

A brand new filter will register in the section reading GOOD filter. After frequent use of your humidifier, the FilterCheck® Indicator will let you know when the filters need to be changed, (see Figure 2).

CLEANING / MAINTENANCE

When the needle is in the CHANGE section, this means the proper amount of moisture is not getting into your air due to the excessive minerals and sediment that have become trapped on your filters. At this point, you should replace your filter. It is important to change your filter as indicated to obtain stated performance level.



To replace the filter, follow the steps below:

1. Turn the unit off and disconnect from the electrical outlet.
2. Remove the tank and main housing to access the base tray.
3. Remove wick and discard.
4. Follow the weekly cleaning instructions.
5. Insert new filter.
6. Repeat Operating Instructions steps.

It will take about 30 minutes for the humidifier to reach maximum output.

NOTE: You can purchase replacement filters (model HWF75/HFZ21) at a local retailer, by calling 1-800-253-2764, or by visiting www.bionaire.com. It is recommended that a replacement filter is purchased for uninterrupted use.

CLEANING AND MAINTENANCE INSTRUCTIONS

Humidifiers provide comfort by adding moisture to dry, heated indoor air. To benefit most from the humidifier and avoid product misuse, follow all instructions carefully. Please note that this is an electrical appliance and requires attention when in use.

In addition, if you do not follow the recommended care and maintenance guidelines, micro-organisms may be able to grow in the water within the water tank. You must routinely follow the cleaning procedures that follow in order to ensure proper, efficient operation of your humidifier. Proper maintenance and cleaning is essential to the continued performance of your unit and the avoidance of algae or bacteria build-up.

CARACTERISTICA - FUNCIONAMIENTO LIMPIEZA / MANTENIMIENTO

pantalla parpadeará 00 y las flechas arriba y abajo pueden ser presionadas para ajustar el temporizador hasta 16 horas en incrementos de una, una vez que se llega a las 16, si se sigue presionando el botón el ciclo volverá a 00 horas. La luz de temporizador se iluminará a indicar que el temporizador está activado. Entonces la pantalla parpadeará 00 y el botón arriba puede ser presionado de nuevo para aumentar las horas para encenderlo (en la última configuración) de 1 a 16 en incrementos de una hora. La unidad se encenderá cuando el tiempo se cumpla, si la unidad se enciende el temporizador se desactivará. La luz de temporizador se iluminará para indicar que el temporizador está activado. Una vez que se llega a las 16 horas, si se vuelve a presionar el botón de temporizador el ciclo volverá a las 00 horas.


Temporizador de encendido automático

Mientras la unidad está apagada, los botones de arriba y abajo se presionan simultáneamente por dos segundos y la pantalla parpadeará 00 y el botón arriba puede ser presionado de nuevo para aumentar las horas para encenderlo (en la última configuración) de 1 a 16 en incrementos de una hora. La unidad se encenderá cuando el tiempo se cumpla, si la unidad se enciende el temporizador se desactivará. La luz de temporizador se iluminará para indicar que el temporizador está activado. Una vez que se llega a las 16 horas, si se vuelve a presionar el botón de temporizador el ciclo volverá a las 00 horas.

REEMPLAZO DE LOS FILTROS

Durante el uso normal de la unidad, los minerales y sedimentos arrastrados por el agua quedan retenidos en el filtro de mecha. Mientras más dura sea el agua, mayor será el número de minerales que contenga, mientras mayor sea el número de minerales en el agua, mayor será la frecuencia en que tenga que cambiar el filtro. Podrá monitorear la vida del filtro de su humidificador con el indicador FilterCheck®. El indicador FilterCheck® sólo leerá el estado del filtro cuando el humidificador esté en funcionamiento.

NOTE: Podría tardar hasta 60 minutos de funcionamiento para que el indicador FilterCheck® pueda reflejar el estado del filtro.



Daily Maintenance

1. Be sure the unit is OFF and is disconnected from the electrical outlet.
2. Remove the housing and the tank from the humidifier and place in sink or tub.
3. Carry the base of the unit to the sink, remove the wick, place in sink, drain any remaining water and rinse thoroughly to remove any sediment or dirt. Wipe clean, and dry with a clean cloth or paper towel.
4. Drain the water from the tank into the sink and rinse tank thoroughly. Wipe clean, and dry with a clean cloth or paper towel.
5. Put filter back in, replace the housing, then refill tank with cool tap water as instructed earlier in the Filling Instructions. Do not overfill.
6. Follow Operating Instructions.

Weekly Maintenance

Remove scale:

1. Repeat steps 1-4 above.
2. Clean the base by partially filling the base with one 8-oz cup of undiluted white vinegar, or by using Cleanse Clean® solution (Model S1710) by the manufacturer. Leave this solution in the base for 20 minutes, while cleaning all the interior surfaces with a soft brush. Remove base scale by wiping the base with a cloth dampened with undiluted white vinegar.
3. Rinse with clean warm water to remove the cleaning solution before disinfecting the tank.

To Disinfect Humidifier Base and Tank:

1. Fill humidifier tank 1/2 full with water and 1/2 teaspoon of chlorine bleach.
2. Fill each tank 1/2 full with water and 1/2 teaspoon of chlorine bleach.
3. Let the solution stand for 20 minutes, swishing every few minutes. Wet all surfaces.
4. Carefully empty the base and tank after 20 minutes, and rinse with water until you cannot detect any bleach smell. Dry with a clean cloth or paper towel.
5. Check the FilterCheck® Indicator to see if it is time to replace the filters. Depending on water hardness in your area, it may be necessary to change the filter every 1-2 months. Re-insert the wick filter.
6. Refill the water tank as directed with cool tap water, replace the humidifier housing, and turn the unit on.

Un filtro completamente nuevo se registrará en la sección denominada Filtro BUENO. Después de haber usado con bastante frecuencia su humidificador, el indicador FilterCheck® le avisará cuando tiene que cambiar su filtro (observe la Figura 2).

Cuando la aguja esté en el área CAMBIAR, significa que la unidad no está emitiendo la humedad necesaria debido a la excesiva cantidad de minerales y sedimentos que se encuentran retenidos en los filtros. Ahora es cuando debe reemplazar el filtro. Para obtener un mejor rendimiento, es importante cambiar su filtro según sea indicado.

Para reemplazar el filtro, siga los siguientes pasos.

1. Apague la unidad y desenchufela del tomacorriente.
2. Quite el tanque de agua y cubierto principal para acceder a la bandeja de la base.
3. Retire y desheche la mecha.
4. Siga las instrucciones para la limpieza semanal.
5. Inserte el nuevo filtro.
6. Repita los pasos de las instrucciones de uso.

Tomará aproximadamente 30 minutos para que el humidificador alcance su potencia máxima.

NOTE: Puede comprar repuestos de filtros (modelo HWF75/HFZ21) en una tienda local, llamando al 1-800-253-2764, o visitando www.bionaire.com. Se recomienda que compre un filtro de repuesto para no interrumpir el funcionamiento de la unidad.

INSTRUCCIONES DE LIMPIEZA Y MANTENIMIENTO

Los humidificadores proveen confort agregando humedad al aire seco de los ambientes interiores calefaccionados. Para beneficiarse al máximo de los humidificadores y evitar su mal uso, siga todas las instrucciones cuidadosamente. Tenga en cuenta que éste es un artefacto eléctrico que requiere atención cuando esté en uso. Además, si no se siguen las recomendaciones para el cuidado y mantenimiento, pueden crear microorganismos en el agua dentro de los tanques. Se deben ejecutar rutinariamente los procedimientos de limpieza que se indican a continuación para asegurar el funcionamiento adecuado y eficiente del humidificador que son esenciales para el rendimiento óptimo constante de la unidad y para evitar la formación de algas y bacterias.